

The following table provides a drawing cross-reference for Fuji Electric's **FRENIC-Multi** open chassis drives.

<i>FRENIC-Multi</i> (Open Chassis)			
Voltage/Phase	Hp	Drive Model Number	Drawing Number
230V 1-phase	1/8	FRNF12E1S-7U	ROA701306
	1/4	FRNF25E1S-7U	
	1/2	FRNF50E1S-7U	ROA701307
	1	FRN001E1S-7U	ROA701308
	2	FRN002E1S-7U	ROA701309
	3	FRN003E1S-7U	ROA701310
230V 3-phase	1/8	FRNF12E1S-2U	ROA701311
	1/4	FRNF25E1S-2U	ROA701312
	1/2	FRNF50E1S-2U	
	1	FRN001E1S-2U	ROA701305
	2	FRN002E1S-2U	ROA701301
	3	FRN003E1S-2U	
	5	FRN005E1S-2U	ROA701302
	7.5	FRN007E1S-2U	ROA701303
	10	FRN010E1S-2U	
	15	FRN015E1S-2U	ROA701304
	20	FRN020E1S-2U	
460V 3-phase	1/2	FRNF50E1S-4U	ROA701300
	1	FRN001E1S-4U	ROA701301
	2	FRN002E1S-4U	
	3	FRN003E1S-4U	
	5	FRN005E1S-4U	ROA701302
	7.5	FRN007E1S-4U	ROA701303
	10	FRN010E1S-4U	
	15	FRN015E1S-4U	ROA701304
	20	FRN020E1S-4U	

Notes:

1. For additional product information please see the *FRENIC-Multi* instruction manual INR-SI47-1204-E.

The following table provides a drawing cross-reference for Fuji Electric's **FRENIC-Multi** drives including the appropriate NEMA 1 Kit.

FRENIC-Multi (Including NEMA 1 Kit)				
Voltage/Phase	Hp	Drive Model Number	NEMA 1 Kit Model Number	Drawing Number
230V 1-phase	1/8	FRNF12E1S-7U	NEMA1-0.2E1-27	ROA701313
	1/4	FRNF25E1S-7U	NEMA1-0.2E1-27	ROA701313
	1/2	FRNF50E1S-7U	NEMA1-0.4E1-27	ROA701314
	1	FRN001E1S-7U	NEMA1-0.75E1-7	ROA701318
	2	FRN002E1S-7U	NEMA1-1.5E1-7	ROA701319
	3	FRN003E1S-7U	NEMA1-3.7E1-24	ROA701321
230V 3-phase	1/8	FRNF12E1S-2U	NEMA1-0.2E1-27	ROA701313
	1/4	FRNF25E1S-2U	NEMA1-0.2E1-27	ROA701313
	1/2	FRNF50E1S-2U	NEMA1-0.4E1-27	ROA701314
	1	FRN001E1S-2U	NEMA1-0.75E1-2	ROA701315
	2	FRN002E1S-2U	NEMA1-2.2E1-24	ROA701320
	3	FRN003E1S-2U	NEMA1-2.2E1-24	ROA701320
	5	FRN005E1S-2U	NEMA1-3.7E1-24	ROA701321
	7.5	FRN007E1S-2U	NEMA1-7.5E1-24	ROA701322
	10	FRN010E1S-2U	NEMA1-7.5E1-24	ROA701322
	15	FRN015E1S-2U	NEMA1-15E1-24	ROA701323
460V 3-phase	20	FRN020E1S-2U	NEMA1-15E1-24	ROA701323
	1/2	FRNF50E1S-4U	NEMA1-0.4E1-4	ROA701316
	1	FRN001E1S-4U	NEMA1-0.75E1-4	ROA701317
	2	FRN002E1S-4U	NEMA1-2.2E1-24	ROA701320
	3	FRN003E1S-4U	NEMA1-2.2E1-24	ROA701320
	5	FRN005E1S-4U	NEMA1-3.7E1-24	ROA701321
	7.5	FRN007E1S-4U	NEMA1-7.5E1-24	ROA701322
	10	FRN010E1S-4U	NEMA1-7.5E1-24	ROA701322
	15	FRN015E1S-4U	NEMA1-15E1-24	ROA701323
	20	FRN020E1S-4U	NEMA1-15E1-24	ROA701323

Notes:

1. For additional product information please see the FRENIC-Multi instruction manual INR-SI47-1204-E.