






Note: () in Type line replances any of codes listecd in Table 1.
注) 形式の口には表 1 のコードが入ります

Type 形式	Type 形式
FRN0.75AR1L-2J	FRN001AR1 -2U
FRN1.5AR1L-2J	FRN002AR1 -2U
FRN2.2AR1L-2J	FRN003AR1 -2U
FRN3.7AR1L-2J	FRN005AR1 -2U
FRN3.7AR1L-4J	FRN001AR1 -4U
FRN5.5AR1L-4J	FRN002AR1 -4U
FRN7.5AR1L-4J	FRN003AR1 -4U
	FRN005AR1 -4U
	FRN007AR1 -4U
	FRN010AR1 -4U
	FRN001AR1 -5U
	FRN002AR1 -5U
	FRN003AR1 -5U
	FRN005AR1 -5U
	FRN007AR1 -5U
	FRN010AR1 -5U


Code コード
M
L

DIMENSIONS IN mm [inch]


REVISEMENTS	a) Changed application type. 2014-06-16 KM/Y.GIGA/H.KONO/M.MOCHIZUKI	DRAWN	DATE	NAME	APPROVED	TITLE	External Dimensions 外形図 FRENIC-HVAC	DWG. NO. SA496809 (1/2)	a b c
	b) Added application type. 2014-07-22 M.KODAMA/M.NAKAI/H.KONO/M.MOCHIZUKI		2013-10-07	SI/Y.GIGA					
	c) Changed notes. Changed all page 2015-10-06	CHECKED	2013-10-07	E.IWABUCHI	E.IWABUCHI				
	UY/T.YOSHIKAWA/T.YOSHIDA/ J. Ishikawa								
		Fuji Electric Co., Ltd.			REF.				



Control circuit terminal
制御端子詳細



Main circuit terminal
主回路端子詳細



DIMENSIONS IN mm [inch]

Connection Detail 端子詳細			
Terminal No. 端子記号			Size ネジサイズ
Source(Input)	電源入力	L1/R,L2/S,L3/T	M4
Output	出力	U,V,W	
DC power supply	直流電源入力	P(+),N(-)	
Ground	アース	G	
Auxiliary control powerinput	補助電源入力	R0,T0	M3.5
Control cirucuit terminal	制御回路端子		M3

REVISIONS	© Revised error. 2015-10-06	DATE	NAME	APPROVED
	UY/T.YOSHIKAWA/T.YOSHIDA/T. Ishikawa	DRAWN	SI/Y.GIGA	
		CHECKED	E.IWABUCHI	
Fuji Electric Co., Ltd.				REF.

External Dimensions
外形図
FRENIC-HVAC

DWG. NO.	SA496809 (2/2)
DWG. CODE	